

Настройка PPPoE

В адресной строке любого браузера наберите **192.168.0.1**.
Стандартные данные для входа **admin/admin**

Для настройки подключения слева выберите **Internet Settings**

Connection Type – PPPoE

User Name – Логин по договору

Password – Пароль от логина

OK — для подтверждения

The screenshot shows the Tenda router's web management interface. The top navigation bar is orange with the 'Tenda' logo on the left and 'Logout' and 'English' on the right. A sidebar on the left contains menu items: Status, Internet Settings (highlighted in orange), Wireless Settings, Bandwidth Control, Wireless Repeating, Parental Controls, Advanced, and Administration. The main content area displays the 'Internet Settings' configuration page. At the top, 'Connection Type' has three radio buttons: PPPoE (selected), Dynamic IP, and Static IP. Below this is a note: 'Select PPPoE if your internet connection asks for the user name and password.' The 'User Name' field contains the text 'windy'. The 'Password' field is filled with ten dots. At the bottom right of the main area, there are two buttons: 'OK' (orange) and 'Cancel' (grey).

Настройка беспроводной сети

Слева выберите **Wireless Settings**

Wifi Name – Имя сети

Security Mode – WPA/WPA2-PSK Mixed

WiFi Password – Ключ сети

- Status
- Internet Settings
- Wireless Settings**
- Bandwidth Control
- Wireless Repeating
- Parental Controls
- Advanced
- Administration

WiFi ON/OFF

WiFi Name and Password

WiFi Name Hide WiFi (?)

Security Mode

WiFi Password

Multi SSID and Password

Multi SSID Enable Disable

WiFi Name

WiFi Password

WiFi Signal Strength

Signal Strength Low High

