

Настройка роутера.

Для открытия Web-интерфейса маршрутизатора введите в адресной строке браузера адрес **192.168.2.1** и нажмите **Enter**.

Для входа в настройки роутера нажмите на кнопку Login. Откроется окно для ввода пароля. Пароль оставляем пустым и нажимаем на **Submit**.

Login

Before you can change any settings, you need to log in with a password. If you have not yet set a custom password, then leave this field blank and click "Submit."

Password

Default = leave blank

Затем должна открыться следующая страница:

BELKIN Router Setup Home | Help | Logout Internet Status: **Connected**

Status

Language	
Current Language	English
Available Languages	English Français Deutsch Español Nederlands Italiano

Version Info	
Firmware Version	1.01.06 (Jul 29 2008 10:41:04)
Boot Version	V0.05
Hardware	F5D8633-4 v1 (01)
Serial No.	12841863300948

LAN Settings	
LAN/WLAN MAC	
IP Address	192.168.2.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled (1 LAN, 0 WLAN Client)

Internet Settings	
WAN MAC Address	
Connection Type	PPPoE
WAN IP	
Subnet Mask	
Default Gateway	
DNS Address	

Features	
Firewall Settings	Enabled
SSID	
Security	WPA-Personal (PSK)
UPnP	Enabled
Remote Management	Disabled
WPS	Enabled

ADSL		
Type	Fast Path	
Status	SHOWTIME	
	Downstream	Upstream
Data rate(Kbps)	1152Kb	288Kb
Noise Margin	7	24
Output power(dBm)	123	171
Attenuation(dB)	59	31

LAN Setup
LAN Settings
DHCP Client List

Internet WAN
Connection Type
DNS
MAC Address

Wireless
Channel and SSID
Security
Wi-Fi Protected Setup
MAC Address Control

Firewall
Virtual Servers
Client IP Filters
MAC Address Filtering
DMZ
DDNS
WAN Ping Blocking
Security Log

Utilities
Restart Router
Restore Factory Defaults
Save/Backup Settings
Restore Previous Settings
Firmware Update
System Settings

Здесь выбираем пункт **Internet WAN** и подпункт **Connection Type**. Выбираем протокол подключения PPPoE и нажимаем **Next**.



В открывшемся окне вводим **Логин/Пароль** по договору и ждем **Apply Changes**.



Настройка WiFi.

Выбираем пункт **Wireless** затем пункт **Channel and SSID**, здесь ставим **Wireless Channel** и **Extension Channel – AUTO**, Указываем **SSID** - название сети **Wireless Mode** устанавливаем **11b+g+n**, **Broadcast SSID** ставим галочку, **Protected Mode** устанавливаем **OFF**, **Bandwidth** указываем как на картинке и нажимаем **Apply changes**.

The screenshot shows the Belkin Router Setup web interface. The top navigation bar includes the Belkin logo, 'Router Setup', and links for Home, Help, Logout, and Internet Status (Connected). A left sidebar lists various setup categories: LAN Setup, Internet WAN, Wireless, Firewall, and Utilities. The main content area is titled 'Wireless > Channel and SSID' and contains the following configuration options:

- Wireless Channel > 6
- Extension Channel > 2
- SSID > [Empty text field]
- Wireless Mode > 11b+g+n
- Broadcast SSID > More Info
- Protected Mode > Off More Info
- Bandwidth > 20MHz+40MHz auto

Below these settings is a section for 'QoS Configuration' with the following option:

- 802.11e QoS > On More Info

At the bottom of the configuration area are two buttons: 'Clear Changes' and 'Apply Changes'.

Затем слева выбираем пункт **Security**.

Security Mode указываем **WPA/WPA2-Personal(PSK)**, **Authentication - WPA2-PSK**,
Encryption Technique - AES и указываем **Password(PSK)** - пароль от сети wi-fi.

И нажимаем **Apply Changes**.



The screenshot shows the Belkin Router Setup interface. The left sidebar contains a navigation menu with categories: LAN Setup, Internet WAN, Wireless, and Firewall. The 'Wireless' section is expanded, and 'Security' is selected. The main content area is titled 'Wireless > Security'. It features several dropdown menus: 'Security Mode' set to 'WPA/WPA2-Personal(PSK)', 'Authentication' set to 'WPA2-PSK', and 'Encryption Technique' set to 'AES'. Below these is a password input field for 'Password(PSK)'. A large watermark 'PcWinTech.com' is overlaid on the page. Below the password field, there is a checkbox for 'Obscure PSK' and two buttons: 'Clear Changes' and 'Apply Changes'. A descriptive paragraph explains WPA/WPA2-Personal(PSK) and includes a 'More Info' link.

Для сохранения настроек нужно перезапустить роутер, для этого заходим слева в колонке в пункт **Utilities** выбираем там **Restart Router** и жмем соответствующую КНОПКУ.



The screenshot shows the Belkin Router Setup interface. The left sidebar is the same as in the previous screenshot, but the 'Utilities' section is now selected. The main content area is titled 'Utilities > Restart Router'. It contains a paragraph of text: 'Sometimes it may be necessary to Restart or Reboot the Router if it begins working improperly. Restarting or Rebooting the Router will not delete any of your configuration settings. Click the "Restart Router" button below to Restart the Router.' Below the text is a single button labeled 'Restart Router'. A large watermark 'PcWinTech.com' is overlaid on the page.

Появляется следующее окно, жмем ОК:



Перезапуск роутера может занять до 60 секунд. При этом важно не отключать питание маршрутизатора

